

sobro

smart side table



user manual

SOSTB300

welcome to the future of furniture

Get Started

①

Unpack and assemble the table.
Parts and accessories are in the box
located in the Storage Shelf.

②

Connect Bluetooth with the
instructions in this manual.

③

Download and connect the Sobro App.



Scan the QR code to learn more about your Sobro Smart Side Table



sobro

smart side table

| | |
|--|-------|
| Important Safeguards | 6-7 |
| Parts and Features | 8-11 |
| Using the Sobro Speakers | 12 |
| Features and Controls | 14-15 |
| Assembly | 16-17 |
| Attaching the Dimmers | 18 |
| Installing the Power Cord | 19 |
| Connecting the Sobro App | 20-26 |
| Adding a Guest to your Sobro | 28-30 |
| Cleaning & Maintenance | 32 |
| Troubleshooting & Customer Support | 33 |
| Warranty | 34-35 |
| FCC Statement | 37 |

IMPORTANT SAFEGUARDS: PLEASE READ AND SAVE THIS INSTRUCTION MANUAL

When using electrical appliances, basic safety precautions should be followed, including:

- Read all instructions.
- Do not use appliance for other than its intended use. For household use only. Do not use outdoors.
- Remove all bags and packaging from appliance before use.
- For maintenance other than cleaning, please contact StoreBound directly at 1-800-898-6970 from 7AM-7PM PST Monday-Friday or by email at support@storebound.com
- StoreBound shall not accept liability for damages caused by improper use of the appliance.
- The safety and operating instructions should be retained for future reference.
- Heed all warnings. All warnings on this product and in the operating instruction manual should be adhered to.
- Refrain from using attachments that are not recommended by the appliance manufacturer, as this may result in fire, electric shock, or personal injury.
- Do not use the product near water and/or moisture, for example: near a bathtub, sink, in a wet basement; or near a swimming pool.
- Clean only with a slightly damp, lint-free cloth. Unplug this product from the wall outlet before cleaning.
- Do not block any ventilation openings. Install the appliance in accordance with the manufacturer's instructions.
- Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating.
- This product should never be placed near or above a radiator or heat source. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided and the manufacturer's instructions have been adhered to.
- The cord to this appliance should be plugged into a 3-prong electrical wall outlet.
- A short power supply cord is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. An extension cord may be used if care is exercised in its use. If an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance. The extension cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.
- Do not operate this appliance with a damaged cord, damaged plug, after the appliance malfunctions, is dropped, or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- Always unplug the appliance when not in use for an extended period of time.
- Upon completion of any service or repairs to this product ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- The product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate

from battery power, or other sources, refer to the operating instructions.

- Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.
- Never push objects of any kind into the product as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid on the product.
- Do not attempt to service this product yourself. Contact StoreBound directly at 1-800-898-6970

from 7AM-7PM PST Monday-Friday or by email at support@storebound.com.

- When replacement parts are required, be sure the service technician uses replacement parts specified by the appliance manufacturer, or those that have the same characteristics as the original part.
- **WARNING** - Please refer to the information on the inside of the drawer for electrical and safety information before installing or operating the appliance.

Location

Place the Sobro Side Table in a dry and well-ventilated room.

Do not place the appliance near a heat source (e.g. radiators, water heaters or similar devices) and do not expose the appliance to direct sunlight.

Ventilation

Do not cover the Cooler Drawer Vent on the back of the Sobro Side Table, as this may result in overheating.



ATTENTION: it is dangerous to use the same multipurpose power outlet for the Sobro table and other home appliances. Please do not use the same power outlet for the table along with any other home appliances.




Before installing your Sobro, choose the location carefully. Avoid placing the Sobro in direct sunlight or close to a heat source. Avoid locations subject to vibrations and excessive dust, cold, or moisture.



Do not open the Circuit Board Cabinet as this will result in damage to the circuitry or electrical shock. If a foreign object should get into the appliance, contact customer service. When removing the power plug from the wall outlet, always pull directly on the plug, never pull the cord.





Contents inside box include:




Table Legs



Power Cord




Dimmers



Aux Cord

Charging Station Detail



① 120V Power Outlets

② USB Ports

③ USB-C Ports

④ 3.5mm Aux Input

⑤ Hotspot Button

Use to connect your Sobro to WiFi and to the Sobro App. See pg. 20 for more details.

⑥ Speaker Button

Use to turn the speakers on and off, connect/disconnect with a Bluetooth device, or pair with the Bluetooth speakers of another Sobro Smart Side Table.

⚠ Do not exceed 800 Watts between devices connected to the Sobro Side Table simultaneously.

NOTE: the USB-C Port may not power a laptop or other large mobile device. Instead use the 120V Power Outlets.

Play music, set an alarm, and more through the Sobro Smart Side Table's speakers.



Bluetooth

Connecting One Table

To connect a device to the Sobro Smart Side Table with Bluetooth, hold down the circular Speaker Button on the back of the Sobro for 3 seconds. A tone from the table will alert you that the Bluetooth functionality is turned on.

A device called "Sobro Smart Side Table (XX:XX)" should appear in the Bluetooth menu of your mobile device. Select this to connect the Sobro.

Pairing Two Tables Together

To pair two Sobro Smart Side Tables together, press the Speaker Button two times on both tables. After 10-15 seconds, you should hear a tone that is synced between the two tables.

Disconnecting

To unsync your mobile device, press the Speaker Button of the Sobro Smart Side Table to turn the Bluetooth off. This also works to disconnect two paired side tables from a phone—make sure to single-press the Speaker Button of the table that is connected to your mobile device.

To unpair two side tables, double-press the Speaker Button on one of the side tables.


NOTE: If you don't disconnect your Sobro Smart Side Table and the Bluetooth function on your phone is on, the Sobro will automatically connect when you are in range. Two synced Sobro Side Tables should remain connected to each other.

Using Aux Input

To use an Aux cord to connect your mobile device to the Sobro Speakers, plug in the cord and then press the Speaker Button to turn the speakers on.

Note: Bluetooth will auto-disconnect once the Aux cord is plugged in.





Sobro App & Bluetooth

These features require the Sobro App to be connected and Bluetooth to be on in order to use the Sobro speakers.



Alarm

Let the Sobro help you wake up more naturally. You can use the Sobro App as a standard Alarm or choose 'Wake Up Process' to gradually increase the volume of the alarm and the brightness of the Back Light.



Bedtime

Set your Bedtime and the Sobro Smart Side Table will automatically dim and/or play Sleep Sounds of your choice. Choose 'Bedtime Process' to ease into the program gradually.



Sleep Aid

Sleep Aid allows you to choose from a range of soothing Sleep Sounds for a better, more restful sleep.

Sobro App

These features can be controlled through the Sobro App and shared with a Guest.



Front Light & Motion Detector

Use the Sobro App to control the brightness and warmth of the Front Light. You can also access settings for the motion detector, which will turn on the Front Light automatically when you walk past.



Back Light

Turn the Back Light on and off using the dimmers on the back of the Sobro or through the Sobro App. Use the App to customize the color or choose from preset scenes.

With the Sobro App, you can also set the pattern of the Back Light to Pulse, Cycle, or Rhythmic, the latter of which will sync to music played through the Sobro Smart Side Table to the lights.

The Back Light can be paired with the Bedtime or Alarm functions for a simulated sunrise.



Cooler Drawer

The Cooler Drawer will turn on automatically when you plug in the Sobro Smart Side Table. You can turn the Cooler Drawer on and off using the app. Since the Cooler Drawer uses a thermoelectric cooling system to keep your Cooler Drawer up to 21°F cooler* than the ambient temperature in the room, you never need to worry about setting the temperature. **Important:** Do not store perishables (like milk) in the Cooler Drawer.

* The Cooler Drawer will not reach a temperature below 41°F.

Side Table


This feature is on the Side Table.




Dual Wireless Charging Pad

The rectangle at the top of your Sobro Smart Side Table is a wireless charging pad with two charging ports, one on each side. Place a compatible device on either side of the rectangle to wirelessly charge. You should see the lights on the Dual Wireless Charging Pad illuminate to indicate that the device is charging.


Charging position for phones illustrated below. The Dual Wireless Charging Pad will only work with devices that have wireless charging capabilities.






1

Find the four attachable legs of your Sobro in the cardboard box that comes inside the Sobro's Storage Shelf.




2

When attaching four legs to your Sobro, use the foam shipping inserts or a blanket to serve as a cushion for the table to rest on. Carefully lift your Sobro Side Table and place it on its side.




3

Screw your desired set of legs into the Leg Bracket. Screw in each leg until it is fully secure.




4

Repeat the process with the other three legs of the Sobro. Remember to always protect the corners without legs by using either one of the foam inserts or a blanket to avoid damaging the table.




The Sobro comes with two attachable Dimmers in the same container as the legs of the table. These attach to the back of the Sobro and allow you to adjust the brightness of the Back Light manually. Both Dimmers function the same way, so control of the Back Light is always within reach.

To attach the Dimmers, simply slide them onto the small metal rods on the back of the Sobro. Your Sobro's Back Light is now ready to use!




Attach the Power Supply Cord to the table.
Warning: Do not attempt to install the Power Cord until the legs are installed.




Lift up your table and carefully place it down on its legs and then attach the Power Supply Cord to the wall.

Important: This appliance must be plugged into a grounded socket. The power cord that is supplied with the appliance contains the appropriate grounding conductor and grounding plug. The plug must be inserted into a wall outlet that has been grounded in accordance with the existing local codes and ordinances. The required nominal voltage and frequency are indicated on the rating label. Consult a qualified electrician for other concerns. We do not recommend plugging the Sobro into a power strip.




Open the app and click “JOIN NOW” to create your account.




Register with Facebook or enter your email information and click “JOIN NOW.” A confirmation code will be sent to your email address — be sure to check your spam folder. Use the code to confirm your account.

Single Admin




Admins have full control over the Sobro Smart Side Table, and can set the Alarm, Bedtime, and Sleep Sounds, as well as control the lights and the freezer. As a single Admin, register with Facebook or create an account using an email address and password.

Multiple Admins




If you have Multiple Admins in your household, it's easiest to use email to set up, selecting a password you feel comfortable sharing with other users.


While multiple mobile devices can be linked to the Sobro, Multiple Sobro App accounts cannot. The easiest way to connect multiple devices is by the login information for your single Sobro App account.



Once you've logged in, begin by clicking "Add Sobro" and selecting the model of Sobro product you're setting up.




You'll see a screen with brief setup steps, and then you'll be prompted to enter the password of your WiFi. Make sure that your mobile device is connected to the WiFi you wish to connect the Sobro to.



You'll be prompted to hold down the Sobro Hotspot Button at the back of your Sobro table.




This is the Hotspot Button.



Once the light on the Sobro is pulsing, you'll be directed to open the Settings app in your mobile device, where you'll see a local WiFi "Sobro-xxxx-xxxx." Choose that network.




You'll be asked to return to the Sobro App. Your phone is now connected to the Sobro's temporary WiFi hotspot.



You'll now be prompted to replace the temporary WiFi with your own WiFi. The app MAY connect automatically by pressing continue, but if you receive an error message, exit the app and try manually selecting your WiFi through Settings. Then return to the Sobro app.




When you return to the Sobro app, the Sobro should connect after a short loading screen.



Once connected, you'll see a home screen with all of your Sobro devices. From here, you can turn the front and back lights on and off, or click through for more features.

Connecting the Sobro App





To remove a Sobro device from your Sobro App, press the "Edit" button in the upper right-hand corner of the screen, and then press the red minus symbol.




Add a friend as a Guest to give them control over the Sobro's light and Cooler Drawer functions. Have the guest download the Sobro App and create their own account. No login is needed to play music through the Sobro's Bluetooth speakers.

To allow another person full Admin control (including the alarm and sleep features), let them use your Sobro email login to connect their Sobro App.


Important: You cannot control a single Sobro Smart Side Table directly with multiple Sobro App accounts. Share your account login or add a Guest.




- ① Click on the side table.
- ② Click on the gear at the bottom of the Controls screen.




Select Guest Management > Edit.




Click Add User. This will allow you to add your guest using their email, or using the QR code found in the guest's Sobro App under Settings > Account.



Type in the Guest's account email or scan the QR code.



Click Add to add the Guest.



Once this is complete, you will be able to click on the icons to select the Guest's permissions, or turn the permissions off.



Clean the Sobro regularly to avoid the accumulation of dust. Wipe the surface of the table with the included microfiber cloth.

Use a small hand-held vacuum or a soft brush to clean any dust. Do not use abrasive or sharp tools to clean your Sobro.

If you are powering off the table for an extended period of time, clean and dry the Cooler Drawer and store the Sobro in a clean, dry location. Do not place any parts outdoors.

Before cleaning the Sobro, please make sure to turn off the table and remove the plug. Do not submerge or douse any part of the appliance with water or any other liquid. Do not use abrasive or corrosive cleaning agents to clean the Sobro.

IMPORTANT: Do not put ice in the cooler drawer as it may melt and damage the unit.

How To Prevent Odor Build-up:

Foods that may expire easily should not be placed in the Cooler Drawer. Only store non-perishable items in the Cooler Drawer. Store foods in sealed plastic bags.

Keep the Cooler Drawer clean and dry. Clean the drawer on a regular basis

How To Remove Odors:

If your Cooler Drawer begins to develop an odor, clean the Cooler Drawer with a non-corrosive or non-abrasive cleaning agent. Dry the Cooler Drawer with a soft cloth and shut the drawer for 24 hours to remove the smell.

For product support, warranty, and maintenance related questions, please contact StoreBound directly at: 1-800-898-6970 from 7AM - 7PM PST, Monday - Friday, or by email at support@storebound.com.

| | |
|---|--|
| If the Sobro is placed unsteadily. | Adjust the placement of the Sobro by adjusting the four legs under the table. Rotate the legs to adjust. |
| The Sobro table is not chilling ingredients or beverages in the Cooler Drawer. | The Cooler Drawer may be too full. Remove some of the beverages or food in the Cooler Drawer. Ensure the drawer is closed properly. Ensure the Cooler Drawer Vent on the back of the Sobro is properly vented. If the table is still not chilling, call customer service. |
| The Cooler Drawer temperature is high. | The Cooler Drawer is not a refrigerator. It is a thermoelectric cooler and its temperature will generally be about 21°F cooler than the room you place the Sobro in. Ensure that the Cooler Drawer is always closed tightly. Do not place hot food in the Cooler Drawer. Do not overfill the Cooler Drawer. Make sure the Cooler Drawer Vent is not covered so that the Sobro is properly ventilated |
| Odor from Cooler Drawer. | Unit should be cleaned before using for the first time. This will clear any odors that may have been trapped during shipment. Clean unit and Cooler Drawer thoroughly. Any uncovered foods will create a odor. |
| The unit does not turn on. | Assure that the power cord is attached properly. Check to make sure the outlet the table is plugged into has power. |
| The Sobro Smart Side Table is not connecting to the Sobro App: | Your phone is not connected to the WiFi you chose in the Sobro App, or the password you entered in the Sobro App for that WiFi is incorrect. Each Sobro Side Table is only designed to connect to one Sobro App at a time. Ensure other mobile devices are not connected to the Sobro Smart Side Table simultaneously. |
| There is a burning odor during operation. | Unplug the unit and call customer service. |
| I cannot connect via Bluetooth. | Make sure that the Bluetooth functionality of your phone is turned on. Make sure that you are holding the Speaker Button, on the Sobro, down for long enough. This might take up to 5 seconds and the Sobro will beep to alert you that it has activated its Bluetooth. Only one mobile device can connect to the Sobro's Bluetooth at a time. Ensure no other mobile devices are connected. |
| My phone won't charge wirelessly or charges slowly . | Not all phones are capable of wireless charging. Make sure that your phone has this capability. The Wireless Charging Pad has two charging "hot spots." One on either end of the pad. Make sure that your phone is placed on the side of the Wireless Charging Pad and not in the middle. Your phone case may be too thick to charge through. Try removing your phone case. |
| The Charging ports don't charge. | Make sure that your Sobro is connected to a power source. Do not connect devices drawing more than 800 watts as this may cause failure. |

SOBRO RESIDENTIAL LIMITED WARRANTY

FOR RESIDENTIAL INDOOR USE ONLY

FULL ONE YEAR WARRANTY*

For one year from the date of original delivery, this Sobro (a division of StoreBound, LLC) product warranty covers all parts and labor to repair or replace, under normal residential use, any part of the product that proves to be defective in material or workmanship. All service provided by StoreBound under the above warranty must be performed by a Sobro factory certified service, unless otherwise specified by StoreBound. Service will be provided during normal business hours.

FULL TWO YEAR SEALED SYSTEM WARRANTY*

For two years from the date of original delivery, this Sobro product warranty covers all parts and labor to repair or replace, under normal residential use, these parts that prove to be defective in materials or workmanship: compressor, condenser, evaporator, drier and all connecting tubing. All service provided by StoreBound under the above warranty must be performed by Sobro factory certified service, unless otherwise specified by StoreBound. Service will be provided during normal business hours.

TERMS APPLICABLE TO EACH WARRANTY

The warranty applies only to products installed for normal residential use. The warranty applies only to products installed in any one of the 50 states of the United States, the District of Columbia or the 10 provinces of Canada. This warranty does not cover any parts or labor to correct any defect caused by negligence, accident or improper use, maintenance, installation, service or repair.

This warranty is valid for the original retail purchaser from the date of delivery and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Any third party dealers, service centers, or retailers do not have the right to alter the term and conditions of this warranty.

Sobro warrants your product against defects in materials and workmanship when purchased directly from Sobro. This warranty is extended only to the original end-use purchaser or the person receiving the product as a gift, and shall not be extended to any other person or transferee. The warranty is valid from the date of original delivery for a period of 1 year. In the case of a covered warranty defect, Sobro will at its option: (A) repair the product using new or refurbished parts; (B) replace the product with an equivalent new or refurbished product; or (C) provide a partial or full refund of the original purchase price to you in exchange for return of the product.

This warranty does not cover defects or damage arising from improper use or maintenance, normal wear and tear, commercial use, accident or external causes. Unauthorized repair, modification, or customization of your product voids this warranty.

The warranty does not cover the following:

- Accidents, Acts of God, lightning, water, fire, public disturbances, improper ventilation, voltage fluctuations or any cause beyond the control of Sobro.
- Unauthorized modifications carried out to the product in order to comply with local or international technical standards in countries for which this Sobro product was not originally designed.
- The serial number on the product has been altered, deleted, removed or made illegible.
- Damage to the tempered glass of the Sobro Coffee Table.

THE REMEDIES DESCRIBED ABOVE FOR EACH WARRANTY ARE THE ONLY ONES THAT STOREBOUND, LLC WILL PROVIDE, EITHER UNDER THIS WARRANTY OR UNDER ANY WARRANTY ARISING BY OPERATION OF LAW. STOREBOUND, LLC WILL NOT BE RESPONSIBLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM THE BREACH OF THIS WARRANTY OR ANY OTHER WARRANTY, WHETHER EXPRESS, IMPLIED OR STATUTORY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights that vary from state to state.

To obtain warranty service, contact Sobro at support@storebound.com, while including your name, model, and serial number of your unit, along with a brief description of the problem. A factory Return Authorization Number will be sent to you. DO NOT RETURN ANY UNIT WITHOUT FIRST RECEIVING WRITTEN AUTHORIZATION AND SHIPPING INSTRUCTIONS FROM SOBRO.

If the above conditions are met, the purchaser's sole remedy shall be to return the product to SOBRO, in which case SOBRO will repair or replace, at its sole option, the defective product without charge for parts and labor. SOBRO will return a unit repaired or replaced under warranty by shipping same by its usual shipping method from the factory (only) at its expense within the United States of America.

Repair or replacement as provided under this warranty is the exclusive remedy of the consumer/purchaser. Sobro shall not be responsible for any incidental or consequential damage except to the extent provided (or prohibited) by applicable law.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. Thi warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

To receive parts and/or service and the name of Sobro factory certified service nearest you, contact Customer Support at **1-800-898-6970** or email us at support@storebound.com.

*Any opening of the circuit board cabinet or Cooler Drawer parts cabinet by customer or non-Sobro factory certified service provider will void all warranties for this product.

TECHNICAL SPECIFICATIONS

Model #: SOSTB300

Voltage AC120-240V ~ 50/60Hz
Stock#: SOSTB300_20180521_10

IMPORTANT NOTES FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

INDUSTRY CANADA:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et. (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

sobro

smart side table